
Key Instruction





Note:

For key : when in static mode, brightness + and - will be executed; when in the dynamic mode, speed + and - will be executed.

For key : brightness 3%, cold white + warm white.
For key : Short press DIY buttons to display the DIY value; long press(2 seconds) DIY buttons to save the current light state as the DIY value.

Remote control code matching function: power on the device, hold down "ON" key for 5 seconds, the device flashes slowly to indicate successful code matching.

Remote code clearing function: power on the device, hold down "OFF" key for 5 seconds, the device flashes quickly to indicate successful clearing.

